

SECTION 9: PARTS

Table Saw Body Breakdown





Table Saw Body Parts List

| REF | PART # | DESCRIPTION |
|-----|----------|-------------------------|
| 1 | P0690001 | CABINET |
| 2 | PSB88M | CAP SCREW M10-1.25 X 25 |
| 3 | PLW06M | LOCK WASHER 10MM |
| 4 | PW04M | FLAT WASHER 10MM |
| 5 | P0690005 | ANGLE SCALE |
| 6 | P0690006 | STRAIN RELIEF |
| 7 | P0690007 | CABINET PLATE |
| 8 | PS14M | PHLP HD SCR M6-1 X 12 |
| 9 | PW03M | FLAT WASHER 6MM |
| 14 | P0690014 | MOTOR COVER |
| 15 | P0690015 | KNOB M6-1 |
| 18 | P0690018 | CLEANOUT DOOR |
| 19 | P0690019 | DOOR LATCH |
| 20 | P0690020 | KNOB M8-1.25 |
| 21 | PW01M | FLAT WASHER 8MM |
| 22 | PLW04M | LOCK WASHER 8MM |
| 23 | PN03M | HEX NUT M8-1.25 |
| 24 | P0690024 | DUST HOOD |
| 25 | PS05M | PHLP HD SCR M5-.8 X 8 |
| 26 | P0690026 | TABLE |
| 27 | P0690027 | EXTENSION WING |
| 28 | PSB13M | CAP SCREW M8-1.25 X 30 |
| 29 | PLW04M | LOCK WASHER 8MM |
| 30 | PW01M | FLAT WASHER 8MM |
| 31 | P0690031 | STD TABLE INSERT |
| 32 | PSS53M | SET SCREW M5-.8 X 12 |
| 33 | PS08M | PHLP HD SCR M5-.8 X 12 |
| 34 | PS06M | PHLP HD SCR M5-.8 X 20 |

| REF | PART # | DESCRIPTION |
|------|------------|-----------------------------|
| 36 | P0690036 | DADO TABLE INSERT |
| 40 | P0690040 | NAME PLATE RIVET |
| 41 | P0690041 | SHIPPING BRACE |
| 42 | PB74M | HEX BOLT M10-1.5 X 20 |
| 43 | PW04M | FLAT WASHER 10MM |
| 44 | PLW06M | LOCK WASHER 10MM |
| 45 | PN02M | HEX NUT M10-1.5 |
| 46 | P0690046 | DUST CLIP |
| 46-1 | P0690046-1 | UPPER BRUSH |
| 46-2 | P0690046-2 | LOWER BRUSH |
| 47 | PS02M | PHLP HD SCR M4-.7 X 12 |
| 48 | PW05M | FLAT WASHER 4MM |
| 49 | PLW02M | LOCK WASHER 4MM |
| 50 | P0690050 | HOOK |
| 51 | PTLW13M | INT TOOTH WASHER 6MM |
| 52 | P0690052 | LIMIT PLATE |
| 53 | PN06M | HEX NUT M5-.8 |
| 54 | PS06M | PHLP HD SCR M5-.8 X 20 |
| 55 | P069055 | MAG SWITCH ASSEMBLY MS-15 |
| 55-1 | P0690055-1 | CONTACTOR CHINT NC1-18 |
| 55-2 | P0690055-2 | OL RELAY CHINT NR2-25 12~18 |
| 55-3 | P0690055-3 | SWITCH BOX FRONT/BACK |
| 55-4 | P0690055-4 | MAG SWITCH COVER SCREW |
| 55-5 | P0690055-5 | ON/OFF SWITCH CHINT NP2 |
| 56 | P0690056 | SWITCH BRACKET |
| 63 | P0690063 | STRAIN RELIEF |
| 64 | P0690064 | MOTOR CORD 14AWG X 3C |
| 65 | P0690065 | POWER CORD 14AWG X 3C |



Trunnion Assembly Breakdown



Trunnion Assembly Parts List

| REF | PART # | DESCRIPTION |
|-------|------------|-------------------------------|
| 101 | P0690101 | HANDWHEEL LOCK |
| 102 | P0690102 | HANDWHEEL |
| 103 | PSS53M | SET SCREW M5-.8 X 12 |
| 104 | P0690104 | ANGLE POINTER-1 |
| 105 | PSS26M | SET SCREW M5-.8 X 6 |
| 106 | P0690106 | ANGLE POINTER-2 |
| 107 | PSB26M | CAP SCREW M6-1 X 12 |
| 108 | PLW03M | LOCK WASHER 6MM |
| 109 | PW03M | FLAT WASHER 6MM |
| 110 | PN01M | HEX NUT M6-1 |
| 111 | P0690111 | ANGLE POINTER BRACKET |
| 112 | PSB38M | CAP SCREW M5-.8 X 25 |
| 113 | P0690113 | PLATE |
| 114 | PSB31M | CAP SCREW M8-1.25 X 25 |
| 115 | PLW04M | LOCK WASHER 8MM |
| 116 | P0690116 | PIN-LOCK-SHAFT |
| 117 | P0690117 | KEY 5 X 5 X 36 |
| 118 | P0690118 | ANGLE SHAFT |
| 119 | P0690119 | LOCK COLLAR |
| 120 | PSS03M | SET SCREW M6-1 X 8 |
| 121 | PLW12M | LOCK WASHER 18MM |
| 122 | P0690122 | COPPER WASHER 18MM |
| 123 | P0690123 | WORM |
| 124 | PSS01M | SET SCREW M6-1 X 10 |
| 125 | P0690125 | FRONT TRUNNION |
| 126 | PSB72M | CAP SCREW M10-1.5 X 30 |
| 127 | PW04M | FLAT WASHER 10MM |
| 128 | PLW06M | LOCK WASHER 10MM |
| 129 | PN02M | HEX NUT M10-1.5 |
| 130 | P0690130 | BELT SPZ 625 |
| 131 | P0690131 | MOTOR PULLEY |
| 132 | PSS53M | SET SCREW M5-.8 X 12 |
| 133 | PK12M | KEY 5 X 5 X 30 |
| 134 | P0690134 | MOTOR 3HP 220V 1-PH |
| 134-1 | P0690134-1 | FAN COVER |
| 134-2 | P0690134-2 | MOTOR FAN |
| 134-3 | P0690134-3 | R CAP 25M 370V 1-3/4 X 3 |
| 134-4 | P0690134-4 | R CAPACITOR COVER |
| 134-5 | P0690134-5 | S CAP 200M 250V 1-1/4 X 2-3/4 |
| 134-6 | P0690134-6 | S CAPACITOR COVER |
| 134-7 | P0690134-7 | WIRING JUNCTION BOX |
| 135 | P0690135 | ORIENTATION PIN |
| 136 | P0690136 | ROLL PIN 4 X 28 |
| 137 | PB121M | HEX BOLT M12-1.75 X 100 |
| 138 | PW06M | FLAT WASHER 12MM |
| 139 | PLW05M | LOCK WASHER 12MM |

| REF | PART # | DESCRIPTION |
|-----|----------|------------------------|
| 140 | PN09M | HEX NUT M12-1.75 |
| 141 | P0690141 | MOTOR FRAME SUPPORT |
| 142 | PSS14M | SET SCREW M8-1.25 X 12 |
| 143 | PSS19M | SET SCREW M8-1.25 X 30 |
| 144 | PN03M | HEX NUT M8-1.25 |
| 145 | P0690145 | HIGH SHAFT |
| 146 | P0690146 | LOCK NUT M18-1.5 |
| 152 | PB09M | HEX BOLT M8-1.25 X 20 |
| 153 | PN03M | HEX NUT M8-1.25 |
| 154 | PB20M | HEX BOLT M8-1.25 X 35 |
| 155 | P0690155 | FLANGE CASTING SLEEVE |
| 157 | PSS20M | SET SCREW M8-1.25 X 8 |
| 158 | P0690158 | COMPRESSION SPRING |
| 159 | P0690159 | BALL |
| 163 | P0690163 | REAR TRUNNION |
| 164 | P0690164 | ADJUST BOLT |
| 165 | PSB13M | CAP SCREW M8-1.25 X 30 |
| 166 | PW01M | FLAT WASHER 8MM |
| 167 | PLW04M | LOCK WASHER 8MM |
| 168 | PN03M | HEX NUT M8-1.25 |
| 169 | P0690169 | HIGH SHAFT |
| 170 | PK44M | KEY 6 X 6 X 50 |
| 171 | P0690171 | GEARED BEARING HOUSING |
| 172 | PB116M | HEX BOLT M10-1.5 X 45 |
| 173 | PLW06M | LOCK WASHER 10MM |
| 174 | PW04M | FLAT WASHER 10MM |
| 175 | P0690175 | ARBOR NUT |
| 176 | P0690176 | ARBOR FLANGE |
| 177 | P0690177 | BLADE (OPTIONAL) |
| 178 | P0690178 | BLADE ARBOR |
| 179 | PK12M | KEY 5 X 5 X 30 |
| 180 | P6005 | BALL BEARING 6005 ZZ |
| 181 | P0690181 | COLLAR BLADE ARBOR |
| 182 | P0690182 | ARBOR PULLEY |
| 183 | P0690183 | COLLAR BLADE ARBOR |
| 184 | P0690184 | FLANGE RING |
| 185 | PS08M | PHLP HD SCR M5-.8 X 12 |
| 186 | PLW01M | LOCK WASHER 5MM |
| 187 | PW02M | FLAT WASHER 5MM |
| 188 | P0690188 | LOCK NUT M16-1.5 |
| 195 | P0690195 | LEFT BRACKET |
| 196 | P0690196 | RIGHT BRACKET |
| 197 | PSB13M | CAP SCREW M8-1.25 X 30 |
| 198 | PW01M | FLAT WASHER 8MM |
| 199 | PLW04M | LOCK WASHER 8MM |




| REF | PART # | DESCRIPTION |
|-----|----------|------------------------|
| 200 | PN03M | HEX NUT M8-1.25 |
| 201 | P0690201 | BULL GEAR |
| 202 | P0690202 | SPLITTER ADJUST BLOCK |
| 203 | PW03M | FLAT WASHER 6MM |
| 204 | PLW03M | LOCK WASHER 6MM |
| 205 | PSB06M | CAP SCREW M6-1 X 25 |
| 206 | PSS04M | SET SCREW M6-1 X 12 |
| 207 | P0690207 | SPLITTER TIGHTEN CLIP |
| 208 | PLW03M | LOCK WASHER 6MM |
| 209 | PB08M | HEX BOLT M6-1 X 20 |
| 210 | P0690210 | ORIENTATION BAR |
| 211 | PRP49M | ROLL PIN 5 X 25 |
| 213 | PLW01M | LOCK WASHER 5MM |
| 214 | PSB38M | CAP SCREW M5-.8 X 25 |
| 215 | P0690215 | GEAR |
| 216 | PSB47M | CAP SCREW M10-1.5 X 40 |

| REF | PART # | DESCRIPTION |
|-----|----------|------------------------|
| 217 | PW04M | FLAT WASHER 10MM |
| 218 | PLN05M | LOCK NUT M10-1.5 |
| 219 | P0690219 | GEAR SLEEVE |
| 220 | P0690220 | PLATE GEAR |
| 221 | PSS25M | SET SCREW M6-1 X 20 |
| 222 | PN01M | HEX NUT M6-1 |
| 223 | PWF10M | FENDER WASHER 10MM |
| 224 | PW01M | FLAT WASHER 8MM |
| 225 | PLW04M | LOCK WASHER 8MM |
| 226 | PSB14M | CAP SCREW M8-1.25 X 20 |
| 230 | P0690230 | SPACER |
| 231 | P0690231 | POSITION PIN SET |
| 232 | PLW02M | LOCK WASHER 4MM |
| 233 | PSS22M | SET SCREW M4-.7 X 12 |
| 234 | P0690234 | TRUNNION |



Blade Guard Breakdown




| REF | PART # | DESCRIPTION |
|-----|----------|------------------------|
| 315 | PRP39M | ROLL PIN 4 X 20 |
| 319 | P0690319 | TORSION SPRING |
| 321 | P0690321 | SPACER |
| 322 | P0690322 | SUPPORTING ARM |
| 323 | PS47M | PHLP HD SCR M6-1 X 25 |
| 324 | PW03M | FLAT WASHER 6MM |
| 326 | P0690326 | TOP GUARD |
| 327 | PS17M | PHLP HD SCR M4-.7 X 6 |
| 328 | P0690328 | FRONT GUARD |
| 329 | PRP46M | ROLL PIN 6 X 28 |
| 330 | P0690330 | SPACER |
| 331 | P0690331 | SIDE GUARD |
| 332 | P0690332 | GUARD SUPPORT |
| 333 | PFH05M | FLAT HD SCR M5-.8 X 12 |
| 334 | PW02M | FLAT WASHER 5MM |

| REF | PART # | DESCRIPTION |
|-----|----------|------------------------|
| 335 | PLN02M | LOCK NUT M5-.8 |
| 336 | P0690336 | SPECIAL SCR M5-.8 X 15 |
| 337 | P0690337 | SPRING-SPLITTER-ARM |
| 338 | PS22M | PHLP HD SCR M5-.8 X 25 |
| 339 | PLN02M | LOCK NUT M5-.8 |
| 340 | PS09M | PHLP HD SCR M5-.8 X 10 |
| 341 | PS83M | PHLP HD SCR M6-1 X 45 |
| 342 | P0690342 | SPACER |
| 345 | P0690345 | SPACER |
| 346 | PB42M | HEX BOLT M5-.8 X 20 |
| 347 | PLN02M | LOCK NUT M5-.8 |
| 348 | PW02M | FLAT WASHER 5MM |
| 349 | P0690349 | PAWL |
| 350 | P0690350 | SPLITTER |
| 351 | P0690351 | RIVING KNIFE |



Miter Gauge Breakdown




| REF | PART # | DESCRIPTION |
|-----|----------|-----------------------|
| 401 | P0690401 | MITER BAR |
| 402 | P0690402 | GIB |
| 403 | PSS79M | SET SCREW M4-.7 X 6 |
| 404 | PSB41M | CAP SCREW M4-.7 X 14 |
| 405 | P0690405 | MITER RING |
| 406 | PFH30M | FLAT HD SCR M5-.8 X 8 |
| 407 | P0690407 | MITER BODY PIVOT PIN |
| 408 | P0690408 | MITER GAUGE BODY |
| 409 | P0690409 | MITER STOP PIN KNOB |
| 410 | P0690410 | MITER STOP PIN BLOCK |

| REF | PART # | DESCRIPTION |
|-----|----------|------------------------|
| 411 | P0690411 | COMPRESSION SPRING |
| 412 | P0690412 | MITER STOP PIN |
| 413 | P0690413 | FLAT HD SCR M4-.7 X 20 |
| 414 | P0690414 | POINTER MITER GAUGE |
| 415 | PW05M | FLAT WASHER 4MM |
| 416 | PLW02M | LOCK WASHER 4MM |
| 417 | PS07M | PHLP HD SCR M4-.7 X 8 |
| 418 | P0690418 | MITER KNOB |
| 419 | PWF08M | FENDER WASHER 8MM |



Fence Breakdown




| REF | PART # | DESCRIPTION |
|-----|----------|-------------------------|
| 501 | P0690501 | FENCE INSERT |
| 502 | P0690502 | FENCE FACE |
| 503 | PSB01M | CAP SCREW M6-1 X 16 |
| 504 | P0690504 | GLIDE PAD |
| 505 | P0690505 | FENCE SCALE WINDOW |
| 506 | P0690506 | SET SCREW M12-1.75 X 15 |
| 507 | PS09M | PHLP HD SCR M5-.8 X 10 |
| 508 | PLW01M | LOCK WASHER 5MM |
| 509 | P0690509 | INDICATOR |
| 510 | P0690510 | FENCE BODY |
| 511 | P0690511 | SET SCREW |

| REF | PART # | DESCRIPTION |
|-----|----------|------------------------------|
| 512 | PB47M | HEX BOLT M6-1 X 40 |
| 513 | PLN03M | LOCK NUT M6-1 |
| 514 | PB116M | HEX BOLT M10-1.5 X 45 |
| 515 | PLN10M | LOCK NUT M10-1.25 |
| 516 | P0690516 | CAM FOOT |
| 517 | P0690517 | MAGNET |
| 518 | P0690518 | CAM |
| 519 | P0690519 | FENCE LOCK KNOB |
| 520 | PSS32M | SET SCREW M12-1.75 X 30 |
| 521 | P0690521 | SPECIAL LOCKING NUT M12-1.75 |



Model G0690 Extension Table Breakdown




| REF | PART # | DESCRIPTION |
|-----|----------|--------------------------|
| 601 | P0690601 | FENCE INSERT |
| 602 | P0690602 | GUIDE TUBE |
| 603 | P0690603 | SCALE |
| 604 | P0690604 | FRONT RAIL |
| 605 | PSB01M | CAP SCREW M6-1 X 16 |
| 606 | PLW03M | LOCK WASHER 6MM |
| 607 | PW03M | FLAT WASHER 6MM |
| 608 | PB11 | HEX BOLT 5/16-18 X 1-1/2 |

| REF | PART # | DESCRIPTION |
|-----|----------|-----------------------|
| 609 | PLW04M | LOCK WASHER 8MM |
| 610 | PW01M | FLAT WASHER 8MM |
| 611 | P0690611 | REAR RAIL |
| 612 | PB126M | HEX BOLT M8-1.25 X 40 |
| 613 | PN03M | HEX NUT M8-1.25 |
| 614 | P0690614 | TABLE BOARD |
| 615 | PB26M | HEX BOLT M8-1.25 X 30 |



Model G0691 Extension Table Breakdown




| REF | PART # | DESCRIPTION |
|-----|----------|--------------------------|
| 601 | P0691601 | FENCE INSERT |
| 602 | P0691602 | GUIDE TUBE |
| 603 | P0691603 | SCALE |
| 604 | P0691604 | FRONT RAIL |
| 605 | PSB01M | CAP SCREW M6-1 X 16 |
| 606 | PLW03M | LOCK WASHER 6MM |
| 607 | PW03M | FLAT WASHER 6MM |
| 608 | PB11 | HEX BOLT 5/16-18 X 1-1/2 |
| 609 | PLW04M | LOCK WASHER 8MM |
| 610 | PW01M | FLAT WASHER 8MM |

| REF | PART # | DESCRIPTION |
|-----|----------|------------------------|
| 611 | P0691611 | REAR RAIL |
| 612 | PB126M | HEX BOLT M8-1.25 X 40 |
| 613 | PN03M | HEX NUT M8-1.25 |
| 614 | P0691614 | TABLE BOARD |
| 615 | P0691615 | LEG |
| 616 | P0691616 | FOOT |
| 617 | PB28M | HEX BOLT M8-1.25 X 60 |
| 618 | PSB01M | CAP SCREW M6-1 X 16 |
| 619 | PSB14M | CAP SCREW M8-1.25 X 20 |
| 620 | PB26M | HEX BOLT M8-1.25 X 30 |



Labels and Cosmetic Parts Breakdown



| REF | PART # | DESCRIPTION |
|-----|------------|--------------------|
| 701 | P0690701 | FENCE LABEL |
| 702 | P0690702 | GUARD LABEL |
| 703 | PLABEL-14 | ELECTRICITY LABEL |
| 704 | P0690704 | KEEP CLOSED LABEL |
| 705 | PLABEL-63 | UNPLUG POWER LABEL |
| 706 | PLABEL-12A | READ MANUAL LABEL |
| 707 | G8589 | GRIZZLY NAMEPLATE |

| REF | PART # | DESCRIPTION |
|-----|-----------|--------------------------|
| 708 | P0690708 | MODEL # LABEL G0690 |
| 708 | P0691708 | MODEL # LABEL G0691 |
| 709 | P0690709 | MACHINE ID LABEL G0690 |
| 709 | P0691709 | MACHINE ID LABEL G0691 |
| 710 | PLABEL-43 | GLASSES RESPIRATOR LABEL |
| 711 | PPAINT-1 | "GRIZZLY GREEN" PAINT |
| 712 | PPAINT-11 | "PUTTY" PAINT |

! WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or www.grizzly.com to order new labels.

